### **BASIC SERVICE PROCEDURE**

[CR (WITH EURO-OBD)]

### Accelerator Pedal Released Position Learning DESCRIPTION

EBS00036

Accelerator Pedal Released Position Learning is an operation to learn the fully released position of the accelerator pedal by monitoring the accelerator pedal position sensor output signal. It must be performed each time harness connector of accelerator pedal position sensor or ECM is disconnected.

#### **OPERATION PROCEDURE**

- Make sure that accelerator pedal is fully released.
- 2. Turn ignition switch ON and wait at least 2 seconds.
- 3. Turn ignition switch OFF wait at least 10 seconds.
- 4. Turn ignition switch ON and wait at least 2 seconds.
- 5. Turn ignition switch OFF wait at least 10 seconds.

# Throttle Valve Closed Position Learning DESCRIPTION

EBS00037

Throttle Valve Closed Position Learning is an operation to learn the fully closed position of the throttle valve by monitoring the throttle position sensor output signal. It must be performed each time harness connector of electric throttle control actuator or ECM is disconnected.

#### **OPERATION PROCEDURE**

- 1. Make sure that accelerator pedal is fully released.
- Turn ignition switch ON.
- Turn ignition switch OFF and wait at least 10 seconds.
  Make sure that throttle valve moves during above 10 seconds by confirming the operating sound.

# Idle Air Volume Learning DESCRIPTION

EBS00038

Idle Air Volume Learning is an operation to learn the idle air volume that keeps each engine within the specific range. It must be performed under any of the following conditions:

- Each time electric throttle control actuator or ECM is replaced.
- Idle speed or ignition timing is out of specification.

#### **PREPARATION**

Before performing Idle Air Volume Learning, make sure that all of the following conditions are satisfied. Learning will be cancelled if any of the following conditions are missed for even a moment.

- Battery voltage: More than 12.9V (At idle)
- Engine coolant temperature: 70 95°C (158 203°F)
- PNP switch: ON
- Electric load switch: OFF

(Air conditioner, headlamp, rear window defogger)

On vehicles equipped with daytime light systems, set lighting switch to the 1st position to light only small lamps.

- Steering wheel: Neutral (Straight-ahead position)
- Vehicle speed: Stopped
- Transmission: Warmed-up

For A/T models with CONSULT-II, drive vehicle until "FLUID TEMP SE" in "DATA MONITOR" mode of "A/T" system indicates less than 0.9V.

For A/T models without CONSULT-II and M/T models, drive vehicle for 10 minutes.

#### **OPERATION PROCEDURE**

### (ii) With CONSULT-II

- Perform <u>EC-42</u>, "Accelerator <u>Pedal Released Position Learning"</u>.
- 2. Perform EC-42, "Throttle Valve Closed Position Learning".
- 3. Start engine and warm it up to normal operating temperature.
- 4. Check that all items listed under the topic PREPARATION (previously mentioned) are in good order.